

User's Manual MS3767

Slim Plug-In Temperature/Pressure Compensator with Isolated Single Output

Document No: MQDDK-130426-3

Rev. 1.50

Thank you very much for employing MTT products.

Upon receipt of the product(s), please check the affixed label to make sure that the specifications shown therein conform to your requirements. If you find any discrepancies and/or any damage on the product(s), please contact MTT or its local representatives.



You can be assured that all the MTT products are manufactured according to the strict quality control standards.

1. Introduction



For proper operation of the instrument(s), we recommend that you carefully read this manual prior to operation. The manual should be retained for future reference. Please also refer to the relevant product specification sheet.

2. For Safe Operation

Be sure to observe the following safety clauses in your operation of the instrument(s). MTT cannot undertake any responsibility and guarantee for any damage and/or loss caused by improper operation contrary to or neglecting these clauses.

 WARNING	Disregard of this clause may cause fatal harm or serious bodily injury due to fire or electric shock.
 CAUTION	Disregard of this clause may cause bodily harm or damages to nearby objects due to electric shock or other accidental happenings.

The following safety symbols are used on the instrument and in this document:

-  Equipment protected throughout by double insulation or reinforced insulation
-  Functional earth terminal (Do not use this as a protective earth terminal.)

WARNING

- All electrical connections must be made to the terminal block of the socket. All connections and disconnections must be made with no power applied to the instrument. Otherwise, electric shock may result.
- Do not disassemble or modify the instrument, and do not replace the power fuse. Otherwise, fire or electric shock could result.
- Do not allow any foreign matter (metal chips, water, liquid, etc.) to get into the instrument. Should any foreign matter enter the instrument, immediately unplug the power cable, and contact MTT or its distributor.
- When the instrument is used for applications that require higher reliability and safety, such as transportation, communication, power generation control and medical equipment, special consideration should be taken in safety design to prevent such equipment from malfunctioning as a whole system.
- Do not operate the instrument in an explosive atmosphere containing flammable vapors, gases or dusts. Otherwise, an explosion may result.
- Do not place any combustible materials in the vicinity of the instrument.
- Because no power switch is provided on the instrument, the power supply of the instrument cannot be turned off on the instrument side. So, be sure to provide a power circuit breaker for the power source of the instrument. Note that the breaker should be installed in a location close to the instrument for the convenience of operation. And the breaker should be marked as a "disconnecting device" for the instrument.

CAUTION

- Use the instrument within the operating conditions described in the published product specification. Failure to do so may cause fire or damage to the instrument.
- Avoid operating the instrument in locations where extreme temperature changes can cause condensation. Otherwise, it may be damaged and malfunction.
- Avoid operating or storing the instrument in locations where corrosive gases are present or chemical solvents may splash.
- Hot-swapping may not cause immediate defects in the unit, but this should be avoided as far as possible.
- For the sake of safety, installation and wiring must be performed by qualified personnel with expertise in electronics, electricity or instrumentation engineering.

3. Precautions

Be sure to observe the following precautions to ensure proper operation of the instrument(s). If these precautions are disregarded, the performance of the instrument(s) cannot be guaranteed.

For Handling:

- This is a precision instrument. Do not drop or throw the instrument.
- This product contains electronic parts. Do not splash water on the product and do not dip it in water. For installation, select a place where no condensation occurs.
- Avoid storing or installing the instrument in locations subject to direct sunlight, high temperature, dust, high humidity or vibration.

On Power Supply:

Check the power rating on the specification label of the unit to ensure you use the correct power supply.



- Rating 100 to 240V AC, 50 to 60Hz, 5.5VA max. (Input range: 85 to 264V AC, 47 to 63Hz)
- Rating 24V DC, 1.6W max. (Input range: 24V DC±10%)
- Rating 100 to 240V DC, 6.0W max. (Input range: 85 to 264V DC)

For Installation:

- The instrument is intended for indoor installation.
- Refer to section 9 "Mounting / Demounting" to install the unit on a DIN rail or wall.
- Operating environmental conditions:
 - Temperature range: -5 to 55°C
 - Humidity: 5 to 90% RH
 - Altitude up to 2000 meters
- Do not block the vents in the instrument.
- Be careful not to ground the minus (-) terminal of the power supply.
- Use an independent grounding or alternative grounding which does not allow current to flow in.
- The instrument should be installed as shown in the sketch below, namely, in such a position that the label on the front panel is readable in the right direction.
- For effective heat dissipation, allow a space of at least 100 mm above and below the unit. When units are used in multiple stacks, they should be spaced at least 130 mm apart from each other. If the required minimum space is not available, take appropriate heat protection measures by, e.g., placing a partition between the units. Provide a ventilation hole or install a cooling fan to improve airflow. Keep adequate working space in front of and on both sides of the unit.


Installation Position

Typical Installation Example



On Wiring:

- Connections to the instrument should be made to the terminal block. For assignment of the terminals, refer to section 6. The recommended screwing torque is 0.8 to 1.0 Nm.
- For lead wires, use a highly flexible stranded conductor. The recommended nominal cross-section of the lead wire conductor is 0.5 to 2.0 mm².
- The connection of the lead wire to the terminal block should be made with the insulated crimp terminal attached to the end of the wire. Without the insulation, short circuit or electric shock may occur. The recommended thickness of the crimp terminal is 0.7 to 1.0 mm. Note that only up to two (2) crimp terminals can be connected to one (1) terminal screw. In this case, the thickness of the crimp terminal should be not greater than 0.8 mm.



To Avoid Erroneous Measurements:

- In order to reduce the influence of noise, the input/output wire and power supply wire should not be used in a same bundle or same conduit. They should be installed separately with a minimum distance of 200 mm.
- Avoid wiring the signal lines in the vicinity of equipment generating magnetic fields or electromagnetic waves, such as electric motors and large-scale transformers. If inevitable, anti-noise measures such as employment of shielded wires are indispensable.
- At least 30 minutes of warm-up is required prior to operation.
- Any sensor or equipment to be connected to the instrument should be selected in consideration of the input/output impedance of the same. (For detailed specifications, refer to section 4 or the relevant product specification sheet that can be downloaded from our website at <https://www.mtt.co.jp>.)

4. About the Product

The MS3767 compensates for variations in temperature, pressure, or differential pressure, and provides an isolated single output.

Features:


- Pin and socket contacts are gold-plated (0.2µm) to ensure high reliability and long-term stability.
- High dielectric strength of 2,000 VAC between input, output, power, and ground.
- The power unit can deliver AC power ranging from 85 to 264V steplessly without switching to meet varied power requirements.
- Plug-in type for better maintainability
- Drop-proof terminal screws for ease and safety of installation
- Fuse installed in the power line as standard.

Specifications


Input Resistance	Voltage input: 1MΩ min. with or without power. Current input: 250Ω (Standard for 4-20mA DC)
Allowable Input Voltage	Voltage input: 30V DC max., continuous. (Standard for a span up to 10V) Current input: 40mA DC., max., continuous. (Standard for 4 to 20mA)
Input Range	0 to 120% (Any input signal under 0% is assumed to be 0%, while any input signal over 120% is assumed to be 120%.)
Accuracy for Setting Dropout Range	Better than ±0.5% of span. (set value) Better than 0.4% of span. (hysteresis)
Accuracy for Output Clamping Level	Better than ±0.5% of span.
Allowable Output Load	Voltage output: 1V span and up: 2mA max. 10mV: 10kΩ min. 100mV: 100kΩ min. Current output: 750Ω max.
Zero Adjustment	Approx. ±5% of span. (Adjustable by the front-accessible trimmer.)
Span Adjustment	Approx. ±5% of span. (Adjustable by the front-accessible trimmer.)
Equations	Temperature/pressure compensation: $X_0 = \sqrt{\left[\frac{T_B + A}{((T_F - T_Z) \cdot X_2 + T_Z) + A} \cdot \frac{((P_F - P_Z) \cdot X_3 + P_Z) + B}{P_B + B} \right] \cdot X_1}$ Temperature/pressure compensation (without square-root extraction of IN1): $X_0 = \sqrt{\left[\frac{T_B + A}{((T_F - T_Z) \cdot X_2 + T_Z) + A} \cdot \frac{((P_F - P_Z) \cdot X_3 + P_Z) + B}{P_B + B} \right]} \cdot X_1$ Temperature/pressure compensation (without square-root extraction): $X_0 = \frac{T_B + A}{((T_F - T_Z) \cdot X_2 + T_Z) + A} \cdot \frac{((P_F - P_Z) \cdot X_3 + P_Z) + B}{P_B + B} \cdot X_1$ Temperature compensation: $X_0 = \sqrt{\left[\frac{T_B + A}{((T_F - T_Z) \cdot X_2 + T_Z) + A} \right]} \cdot X_1$ Temperature compensation (without square-root extraction of IN1): $X_0 = \sqrt{\left[\frac{T_B + A}{((T_F - T_Z) \cdot X_2 + T_Z) + A} \right]} \cdot X_1$ Temperature compensation (without square-root extraction): $X_0 = \frac{T_B + A}{((T_F - T_Z) \cdot X_2 + T_Z) + A} \cdot X_1$ X ₀ : Calculated output [%] X ₁ : Differential pressure input (IN1) [%] X ₂ : Temperature input (IN2) [%] X ₃ : Pressure input (IN3) [%] T _B : Reference temperature for compensation [°C] T _Z : Temperature input 0% [°C] T _F : Temperature input 100% [°C] P _B : Reference pressure for compensation [kPa] P _Z : Pressure input 0% [kPa] P _F : Pressure input 100% [kPa] A: 273.15, B: 101.32
Accuracy Rating	Input accuracy: ±0.1% of span. Output accuracy: ±0.2% of span.
Temperature Effect	Better than ±0.2% of span per 10°C change in ambient.
Response Time	1s max. (0-90%) with a step input at 100%.
Insulation Resistance	100MΩ min. (@ 500V DC) between input, output, power, and ground.

Dielectric Strength	Input / Output / [Power, Ground]: 2000V AC for 1 minute (Cutoff current: 0.5mA) Power / Ground: 2000V AC for 1 minute (Cutoff current: 5mA)
Surge Withstand Capability	Tested as per ANSI/IEEE C37.90.1-1989.
Storage Temperature	-10 to 60°C

5. External Dimensions & Terminal Assignments




6. Terminal Connection Diagram



7. Terminal Connection


The following steps should be taken prior to the connection.



- (1) Loosen the terminal screw.
- (2) Insert the tip of a screwdriver bit beneath the washer and push it up to make ample room to receive a cable.

8. Power Line Connection


The terminals for power supply connection (① and ②) are covered with a plastic plate for safety (see Fig. 1). Open the cover plate and connect the power lines to the terminals (see Fig. 2). Return the cover plate to its original position (see Fig. 3).



Note: For your safety, do not make any electrical connections or disconnections with power supplied to the instrument. Make sure that all terminal screws are properly tightened each time you finish the tightening.


9. Mounting / Demounting

Mounting the Socket on a DIN rail




Hold the socket with the slide clamp facing down. Hook the upper edge of the cavity in the rear of the socket over the upper blade of the rail (①), then push the lower part of the socket against the lower blade of the rail so as to make the slide clamp engaged firmly with the rail (②).

Demounting the Socket



Push the slide clamp downward with a flat-head screwdriver bit or the like (①), and pull the lower part of the socket toward you (②).

Main Unit Installation / Removal




Installation

- (1) Identify the top and the bottom of the unit and insert the I/O pins straight into the corresponding pin slots (receptacles) on the socket.
- (2) Tighten the fixing screw to fix the unit firmly in position.

Removal

- (1) Loosen the fixing screw.
- (2) Pull out the unit carefully not to bend the I/O pins.

10. Part Names



11. LED Status Indicators


No.	Event	Set Value Indicator (7-segment LED)	CPU Status Indicator LED	Output	Recovery Operation
1	Power ON or start of constant setting	Blinks 3 times (1 s ON - 0.5 s OFF cycle), then displays an equation code for 1 second.	Green LED turns ON for 1 second, and then red LED turns ON for 0.5 second. This cycle is repeated 3 times.	Normal	-
2	Normal operation	OFF	Green LED is ON.	Normal	-
3	Dropout operation	OFF	Red and green LEDs alternately blink at 1 second intervals.	Clamp value	-
4	Selection of constant number	Displays a 2-digit constant number.	Green LED blinks at 1 second intervals.	Value before selection	End of setting
5	Constant setting	Constant	Red LED blinks at 1 second intervals when the constant is positive; Green LED blinks at 1 second intervals when it is negative.	Value before selection	End of setting
6	DAC error	Error code: 1	Red LED is ON.	Typically 0%, but may vary.	None
7	Internal parameter error	Error code: 2	Red LED is ON.	Typically 0%, but may vary.	None
8	Equation parameter error	Error code: 4	Red LED is ON.	Typically 0%, but may vary.	Reconfiguration
9	Temperature constant parameter error	Error code: 8	Red LED is ON.	Typically 0%, but may vary.	Reconfiguration
10	Pressure constant parameter error	Error code: 16	Red LED is ON.	Typically 0%, but may vary.	Reconfiguration
11	Dropout/clamping parameter error	Error code: 32	Red LED is ON.	Typically 0%, but may vary.	Reconfiguration
12	System error	Not defined.	Red LED is ON; Green LED is not defined.	Typically 0%, but may vary.	None

Notes:
 #1: When the Set Value Indicator is turned on, a 3-digit number "888" with dots is displayed, and then an equation code of 1 (for MS3767-A) or 2 (for MS3767-B) appears in the middle digit.
 #6-11: If multiple errors occur, the sum of error code numbers is displayed.
 #12: The red LED may fail to light up.

12. Setting Constants

This section explains how to set constants. The procedure for setting a constant is simple. You just go to the constant selection screen to select a constant number you want to set (see the top right list), then set the constant as desired.

Outline Flow Chart for Constant Setting



List of constants


Const No.	Constant Name	Range Available	Requirements
01	Reference temperature for compensation	-250 to 999.99°C	-
02	Temperature input 0%	-250 to 899.99°C	Set value for temperature input 0% ≤ Set value for temperature input 100% - 100°C
03	Temperature input 100%	-150 to 999.99°C	Set value for temperature input 100% ≥ Set value for temperature input 0% + 100°C
04	Reference pressure for compensation	0 to 9999.99kPa	-
05	Pressure input 0%	0 to 9989.99kPa	Set value for pressure input 0% ≤ Set value for pressure input 100% - 10kPa
06	Pressure input 100%	10.00 to 9999.99kPa	Set value for pressure input 100% ≥ Set value for pressure input 0% + 10kPa
07	Dropout level	5 to 15%	Dropout level ≥ Output clamping level Set values have a hysteresis of 0.4% F.S.
08	Output clamping level	0 to 10%	Output clamping level ≤ Dropout level

Factory Default Settings:


Unless otherwise requested, instruments will be delivered with the factory default settings indicated below:
 Reference temperature for compensation: 0.00°C
 Temperature input 0%: 0.00°C
 Temperature input 100%: 100.00°C
 Reference pressure for compensation: 0.00kPa
 Pressure input 0%: 0.00kPa
 Pressure input 100%: 101.32kPa
 Dropout level: 10%
 Output clamping level: 0%

The Set Value Indicator screen splits a constant into two parts, higher and lower digits, which are selected with the Indicator Selector Switch. The following illustrations show how each constant is displayed on the indicator.


Indication of constants for temperature (constant numbers: 01, 02, 03)
 Temperature-related constants are indicated in 5 digits. The most significant 2 digits are indicated by setting the Indicator Selector Switch to the HI position, while the least significant 3 digits by placing it in the LO position.



Indication of constants for pressure (constant numbers: 04, 05, 06)
 Pressure-related constants are indicated in 6 digits. The most significant 3 digits are indicated by setting the Indicator Selector Switch to the HI position, while the least significant 3 digits by placing it in the LO position.



Indication of constants for dropout and output clamping levels (constant numbers: 07, 08)




Before Setting:

- Make sure that each LED is in accordance with the indication pattern #1 of the table in section 11 and free from any faults.
- The Parameter Selector Switch provides two different functions depending on how long you hold it down. If you hold it down for less than 3 seconds, it serves as selecting a parameter. If you hold it down for 3 seconds or more, it functions as saving the selected parameter. In the following sections, the former case is simply described as "press the Parameter Selector Switch".

12-1. Procedure for Selecting a Constant Number

1. Turn on the power. The CPU Status Indicator and Set Value Indicator will be as shown in the indicator pattern #1 of the table in section 11 (Indication 1).
2. Press and hold the Parameter Selector Switch for at least 3 seconds in the normal operation state (Operation ①).
3. The Set Value Indicator will blink three times and display the current equation code for one second (Indication 2 and 3), followed by the constant number 00*1 (Indication 4).
4. Press the UP or DOWN switch to select a constant number between 00 and 08*2 (Operation ②, Indication 5). To return the unit to normal operation, press the Parameter Selector Switch when the constant number displayed is 00.


- Notes:**
- *1: The constant number is displayed on the two left-most digits of the Set Value Indicator. The CPU Status Indicator blinks green while the number is being displayed on the indicator.
 - *2: Refer to section 12-2 for details on how to set constants.



12-2. Procedure for Setting the Constant

1. Refer to section 12-1 to display the number of the constant you want to set (Indication 1).
2. Press the Parameter Selector Switch (Operation ①), and the value currently saved in the unit will appear on the Set Value Indicator*1 (Indication 2).
3. Use the Indicator Selector Switch to toggle the indicator screen as appropriate (Operation ②). Press the UP or DOWN switch to change the value within the range available for each constant*2 (Operation ③).
4. To save this constant in the unit, press and hold the Parameter Selector Switch for at least 3 seconds*3 (Operation ④).
5. The Set Value Indicator will turn off for one second, then display the set value again (Indication 4).
6. Press the Parameter Selector Switch (Operation ⑤), and the unit will return to constant number indication*4 (Indication 1).

- Notes:**
- *1: The Set Value Indicator screen splits a constant into two parts, higher and lower digits, which are selected with the Indicator Selector Switch. Refer to pages 4 and 5 for information on how the constants are displayed.
 - *2: For details on how to set each constant, refer to sections 12-3 through 12-5. The constant will not change if it is outside the available range or does not meet the requirements.
 - *3: You have only to save the setting with the switch in either the HI or LO position.
 - *4: If you press the Parameter Selector Switch (operation ⑤) in the state of indication 2 or 3, the Set Value Indicator will return to indication 1 without saving the constant.



- Operation ①: Press the Parameter Selector Switch.
- Operation ②: Use the Indicator Selector Switch to toggle between HI and LO.
- Operation ③: Press the UP/DOWN switch to set the constant as desired.
- Operation ④: Press and hold the Parameter Selector Switch for at least 3 seconds.
- Operation ⑤: Press the Parameter Selector Switch.

12-3. Setting Constants for Temperature

Constants supported: Reference temperature for compensation, temperature input 0%, and temperature input 100%

Functions of the switches for setting constants for temperature:

UP/DOWN Switch: Used to select a value. Pressing and holding the switch changes the value faster.

When Indicator Selector Switch is in the HI (top) position:

Each press of the UP/DOWN switch increases/decreases the value by 10°C.

When Indicator Selector Switch is in the LO (bottom) position:

Each press of the UP/DOWN switch increases/decreases the value by 1°C.

Indicator Selector Switch

HI (top) position: Most significant 2 digits of a set value are displayed.

LO (bottom) position: Least significant 3 digits of the value are displayed.

CPU Status Indicator LED

Red LED blinking at 1 second intervals: Positive set value


Green LED blinking at 1 second intervals: Negative set value

Example) When changing the constant for temperature input 100% from -101.00°C to 50.50°C:

Display the set value, -101.00°C.



Start with the setting at the HI side.




*1: Press the UP switch 15 times to change the indicator value from -10 to +4.

In actual calculation, adding [the number of times the switch is pressed × 10°C] to -101.00°C gives +49.00°C.
 $(-101.00^{\circ}\text{C} + [15 \times 10^{\circ}\text{C}] = +49.00^{\circ}\text{C})$
 As a result, the indicator in the LO position reads 9.00.

*2: Adding 1.50°C to 49.00°C gives +50.50°C.

$(49.00^{\circ}\text{C} + 1.50^{\circ}\text{C} = +50.50^{\circ}\text{C})$
 As a result, the indicator in the HI position reads 05.

Start with the setting at the LO side.



*1: Adding 1.00°C to -101.00°C gives -100.00°C.
 $(-101.00^{\circ}\text{C} + 1.00^{\circ}\text{C} = -100.00^{\circ}\text{C})$
 *2: Adding 150°C to -101.00°C gives +50.00°C.
 $(-100.00^{\circ}\text{C} + 150^{\circ}\text{C} = +50.00^{\circ}\text{C})$
 *3: Adding 0.50°C to 50.00°C gives +50.50°C.
 $(50.00^{\circ}\text{C} + 0.50^{\circ}\text{C} = +50.50^{\circ}\text{C})$

12-4. Setting Constants for Pressure

Constants supported: Reference pressure for compensation, pressure input 0%, and pressure input 100%

Functions of the switches for setting constants for pressure:

UP/DOWN Switch: Used to select a value. Pressing and holding the switch changes the value faster.

When Indicator Selector Switch is in the HI (top) position:
Each press of the UP/DOWN switch increases/decreases the value by 10kPa.

When Indicator Selector Switch is in the LO (bottom) position:
Each press of the UP/DOWN switch increases/decreases the value by 0.01kPa.

Indicator Selector Switch


HI (top) position: Most significant 3 digits of a set value are displayed.

LO (bottom) position: Least significant 3 digits of the value are displayed.

CPU Status Indicator LED

Red LED blinking at 1 second intervals

Example) When changing the reference pressure for compensation from 101.32kPa to 89.99kPa:



*1: Subtracting 1.33kPa from 101.32kPa gives 99.99kPa. (101.32kPa - 1.33kPa = 99.99kPa)
As a result, the Indicator in the HI position reads 009.

*2: Subtracting 10kPa from 99.99kPa gives 89.99kPa. (99.99kPa - 10kPa = 89.99kPa)

12-5. Setting Constants for Dropout and Output Clamping Levels

Constants supported: Dropout level, and output clamping level

Functions of the switches for setting constants for dropout and output clamping levels:

UP/DOWN Switch: Used to select a value. Pressing and holding the switch changes the value faster.

When Indicator Selector Switch is in the HI (top) position:
No change. (Nothing indicated)

When Indicator Selector Switch is in the LO (bottom) position:
Each press of the UP/DOWN switch increases/decreases the value by 1%.

Indicator Selector Switch


HI (top) position: Nothing indicated.

LO (bottom) position: A two-digit set value is displayed.

CPU Status Indicator LED

Red LED blinking at 1 second intervals

Example) When changing the set value from 0% to 10%:



13. Adjustment

Since the unit is precisely factory-adjusted before shipment, no further adjustment is needed at the user's side. Adjustment of signal conditioners requires technical expertise and fine craftsmanship. We recommend that you use adjustment service of MTT to save costs and ensure accuracy. Please contact MTT or its local representatives. Just for your reference, the adjustment procedure is described below.


13-1. Preparation

- For the terminal assignments, refer to section 5.
- The wiring work should be performed with no power applied to the instrument.
- Wiring should be connected to the terminal block.
- At least 30 minutes of warm-up is required before adjustment.
- The accuracy of measuring equipment to be used for calibration must be much higher than that of the instrument to be adjusted.
- Refer to section 12 and set each constant to its factory default setting.

13-2. Adjustment Procedure

- (1) Connect the unit as illustrated below.
- (2) Adjust the voltage or current source to generate signals equivalent to 4% (IN1), 0% (IN2), and 0% (IN3) of the input range of the unit.
- (3) Slowly turn the ZERO Trimmer to get 20%* output while applying the inputs as above.
- (4) Adjust the voltage or current source to generate signals equivalent to 100% (IN1), 0% (IN2), and 0% (IN3) of the input range of the unit.
- (5) Slowly turn the SPAN Trimmer to get 100% output while applying the inputs as above.
- (6) Repeat steps (2) through (5) until zero and span are precisely adjusted.
- (7) Adjust the voltage or current source to generate 25%, 50% and 75% of the input signal range of the unit and record the values of output signals to confirm they are linearly proportional.

* For 0 to 20mA output, 20% should be interpreted as 0.5%.



14. Maintenance and Inspection

Check the unit for proper characteristics and settings about once every two years.

15. Warranty Period and Scope

[Warranty Period]

MTT's hardware products are warranted for a period of seven (7) years from the date of shipment.

[Warranty Scope]

- 1) MTT warrants that its hardware products are free from defects in materials and workmanship and conform to its product specifications.
- 2) MTT ships the products under its appropriate quality management system and quality control, but does not warrant, expressed or implied, that the operation, output, or indication of the hardware will be uninterrupted or error free. MTT shall not be liable and make no warranty for any damage to or any safety or performance trouble in the customer's or any other third party's equipment if the operation, output, or indication is interrupted or faulty.
- 3) If, during the warranty period, the product proves to be defective when used in accordance with the relevant user's manual, the product will be repaired or replaced.
- 4) This warranty does not apply to any malfunction or failure resulting from the following:
 - a. Improper or incomplete maintenance or calibration,
 - b. Any other cause, which does not relate with the delivered product,
 - c. Modification or repair by any person other than MTT, and
 - d. Natural disasters or other unavoidable accidents, for which MTT is not liable.